

# How To add the DVD reader on Altos R520

1

In the package there is the DVD reader and four screws. Please take the blue DVD driver holder in the server accessory kit.




2

Place the blue plastic holder behind the DVD and secure it with two screws.



3


Plug the DVD drive into your server and check that the lock mechanism (blue plastic part) holds the drive firmly in place.



# How To add the DVD reader on Altos R720


1

In the package there is the DVD reader and four screws. Please take the metal support and the small board in the accessory kit of the server.




2

Connect the small board to the rear part of the DVD reader.




3

Plug the DVD drive into the metal support and screw the small board to fix it to the metal part.



4

Plug the DVD drive into your server and check that the lock mechanism (blue plastic part) holds the drive firmly in place.



46.DVDSL.001

All the How To guides can be found on <http://support.acer-euro.com/documents/howto/SO.DVDSL.001> - DVD reader combo CD/RW slimline for rack servers R510,R520,R710,R720,R910.

acer